



**JAMES BARONE RACING
AFTERMARKET PARTS AND ACCESSORIES**

JBR Oil Dip Stick Handle Installation Instructions

Tooling:

- ✓ Pliers
- ✓ Small hammer
- ✓ Small nail

Parts List:

- ✓ 1 Oil dip stick handle

1. Start by removing the factory oil dip stick from the vehicle.
2. Lay it across the opening of the pliers with the roll pin facing straight up.
3. Using a small nail and a hammer, tap the roll pin out being careful not to lose the roll pin.



4. Remove the factory dip stick handle and replace with your new JBR Oil Dip Stick Handle.
5. With a hammer tap the roll pin in just enough that it is only part way through.
6. Line up the roll pin with the hole in the dip stick.
7. Then tap the roll pin in until it's flush.



**Congratulations!! You've now completed the installation of
your new JBR Oil Dip Stick Handle!!**